								701	00A-	-0
S	Е	R	V		С	Е	Ν	0	Т	
	70100. 100-600			-		S	SUPERSEDE	S: NON	E	
Seri	ial Numb	<b>ers:</b> 000	0U00000	/ 36031	U00846					
Мо	dificatio	on to e	liminate	loos	e batte	ry conne	ctions.			
To l	Be Perfor	med By	: HP-Qua	alified l	Personne	1				
Par	ts Requir	ed:								
HP	P/N	D	escription	1		Quantity				
8150 1420	0-0449 0-0447 0-0338 0-0312	E	Vire (Red) Wire (Blac Battery Heat Shrir	ck)		35 mm 35 mm 1 10 mm				
Situ	ation:									
the l back	battery ho	lder due	to the lead	ds of th	ne holder	getting spe	n have an inter ad. The result apparent since	is that the	battery	1
									Continue	ed
						۵	DATE: July <sup>^</sup>	1997		
_	FRATIVE	_		JN						
JE NO	DTE CLASSI	FICATION	:							

MODIFICATION RECOMMENDED										
ACTION CATEGORY:	<ul> <li>☐ IMMEDIATELY</li> <li>■ ON SPECIFIED FAILURE</li> <li>☐ AGREEABLE TIME</li> </ul>	STANDARDS: LABOR 1.0 Hours								
LOCATION CATEGORY:	□ CUSTOMER INSTALLABLE □ ON-SITE ■ HP LOCATION	SERVICE     RETURN     USED     RETURN       INVENTORY:     SCRAP     PARTS:     SCRAP       SEE TEXT     SEE TEXT     SEE TEXT								
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	HP RESPONSIBLE UNTIL: July 1999								
AUTHOR: PN	ENTITY: E600	ADDITIONAL INFORMATION:								

© 1997 HEWLETT-PACKARD COMPANY PRINTED IN U.S.A.




## **Solution / Action:**

Using the procedure included in Figure 1 and Figure 2, replace the battery with solder-in battery and solder the battery leads in the same holes as the battery holder. Once the battery is changed it will be necessary to re-enter the serial number. To re-enter the serial number follow the procedure in the Troubleshooting section of the Service Manual. The serial number should be entered in the format 1234U56789.

70100-60003 MPU & POWER BOARD BATTERY MODIFICATION

- 1. Cut wires (8150-0447and 8150-0449) to approximatly 35mm in length.
- 2. Strip both ends of the wires as required.
- 3. Wrap one end of the wires around and solder to the termination tabs of battery (1420-0338).
  - NOTE: Solder the black wire (8150–0447) to the negative termination tab of the battery and the red wire (8150–0449) to the positive termination tab.
- Insulate battery termination tabs with Heatsink (0890-0312). As shown in Figure 1 below.



## 70100-60003 PCA BATTERY MODIFICATION

## STEPS

- 5. FIT BATTERY (1420-0338) INTO BATTERY HOLDER (1400-1465).
  - NOTE: ENSURE POSITIVE (+) AND NEGATIVE (-) TERMINATIONS ARE CORRECTLY ALIGNED.
- 6. SOLDER BATTERY HOLDER AND BATERRY TERMINATION WIRES TOGETHER INTO PC BOARD.
- SECURE BATTERY IN THE HOLDER. WITH A TIE-WRAP AS SHOWN IN FIGURE 2.

