

S E R V I C E N O T E

SUPERSEDES: None

5DX Structural Process Test Systems**Series II Bar Code Reader Installation****Situation:**

The Software Release 5.1 included changes to the Bar code Reader Configuration process to allow more variables in the customer's choice of barcode labels. If "bcrintit" is run and the system is configured for multiple heads the program will lock up.

Solution:

"bcrintit.cfg" in the "CALIB" dir. is configured for a stand alone read head. Edit this file to configure for multiple heads prior to running "bcrintit" .

DATE: July 1998

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR:

KP

ENTITY:

0980

ADDITIONAL INFORMATION:

No Rework Required