								8	115	0A-	06
S	Ε	R	V	I	C	Ε		N	0	Т	Ε

Supersedes: NONE

**Serial Numbers: ALL** 

The instrument starts to boot but eventually the front panel display will stay dark.

**Parts Required:** 

P/N Description Qty.

**NONE** 

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:								
INFORMATION ONLY								
AUTHOR: HK	PRODUCT LINE: PL24							
ADDITIONAL INFORMATION:								

© AGILENT TECHNOLOGIES, INC. 2008 PRINTED IN U.S.A.



October 6, 2008

Rev. 15

Page 2 of 2 81150A-06

## **Situation:**

You switch on the instrument and the instrument seems to boot normally.

You will see the following progress on the display:





However, after sequence above the front panel display stay dark.

Try to reboot the instrument at least 2 times. Disconnect the power cord and wait for at least 30 seconds before re-connecting and restarting again.

## **Solution/Action:**

The communication between the processor board and the main board is not working correctly or is broken completely.

.

- 1. Try to reboot the instrument at least 2 times. Disconnect the power cord and wait for at least 30 seconds before re-connecting and restarting again.
- 2. Take the Service Guide of the 81150A and open chapter "How to Remove and Replace the 81150A Main Board".
- 3. Replace the main board assembly. Do not separate processor board and main board.

If you have any questions contact: