									E31	01A	-12
S	Е	R	V	Ι	С	Е		Ν	0	Т	Е
E31	101A: 4	071A	Semico	nduc	tor Pa	rametri			S: NON	E	
Seria	al Numbo	ers: See	Duplicat	e Servi	ce Notes	.					
Chu	uck Con	nectio	n Cable	e Beca	ame Lo	onger					
Dup	licate Sei	rvice No	tes:								
E3101A-12 Serial Numbers: JP10D00101 / JP10D00300											
JP20D00301 / JP20D00359 E3101K-12 Serial Numbers: JP10E90101 / JP10E90103 E3102A-01 Serial Numbers: JP10G20101 / JP10G20108											
To E	Be Perfor	med By	Agilent-	Qualifi	ied Perso	onnel					
Part	s Requir	ed:									
P/N		De	scription			Quanti	ity				
E312	20-61661	CAE	LE ASS	Y		1					
Situ	ation:										
throu	ugh the ca	uble hold	ing of the	e testhe	ad frame	the chuck . The heat he cable he	-shink pr	revents t	he chuck	C	
										Continue	d.
							DATE:	Nover	mber 199	99	

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

MODIFICATION RECOMMENDED

ACTION CATEGORY:	IMMEDIATELY ON SPECIFIED FAILURE AGREEABLE TIME	STANDARDS: LABOR 1.0 Hours						
LOCATION CATEGORY:	CUSTOMER INSTALLABLE ON-SITE SERVICE CENTER	SERVICE INVENTORY:	RETURN SCRAP SEE TEXT	USED PARTS:	RETURN SCRAP SEE TEXT			
AVAILABILITY:	AVAILABILITY: PRODUCT'S SUPPORT LIFE		AGILENT RESPONSIBLE UNTIL: November 2001					
AUTHOR: TW ENTITY: 3300		ADDITIONAL INFORMATION:						

© 1999 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



Solution / Action:

Replace the old chuck connection cable (P/N E3120-61671) to the new cable (P/N E3120-61661) when installing HPSMU. To replace the old chuck connection cable, use the following procedures:

- 1. Remove the testhead cover of the measurement pin side.
- 2. Remove the inner plate.
- 3. Disconnect the chuck connection cable.
- 4. Remove the air duct.
- 5. Remove the TH PS cable connector assembly.
- 6. Remove the side panel.
- 7. Remove the panel of AUX port connectors. Loosen the four screws of it. Pull the assembly a few inches.
- 8. Remove the chuck connection cable assembly. Use the 5/8 box wrench.
- 9. Install the new chuck connection cable assembly.
- 10. Install the panel of AUX port connectors.
- 11. Install the side panel.
- 12. Install the TH PS cable connector assembly.
- 13. Install the air duct.
- 14. Connect the chuck connection cable.
- 15. Install the inner plate.
- 16. Install the testhead cover.

After replacing the chuck connection cable, perform a full diagnostics.

Necessary parts are supplied from GSL.

If you have any question, please send your message to "HSTD, SVC-SUPPORT".