HALLINGLL, CEPNARD J

## ERVICE N ТЕ S 0

Supersedes: None

## **1980B OSCILLOSCOPE MEASUREMENT SYSTEM** Serials Prefixed 2131A- and Below **OPERATING/PROGRAMMING COMPATIBILITY** (between different vintage instruments)

If the user desires to update older 1980B's to the same operating configuration as those prefix 2142A- and above order ROM kit, HP Part No. 01980-69507, and install. No improvement in performance or measurement capability will result from this change, only compatibility of operation.

To update a 1980B prefix 2131A- and below with a Waveform Storage Option installed to the same operating configuration as 1980B's prefix 2142A- and above (with Waveform Storage Option installed), order the ROM kit above and Display panel bezel assembly 01980-60215. Per instructions in the 1980B Service Manual, remove Display panel, assembly A16. Remove old bezel assembly A16A2 and replace with new assembly and install ROM kit. Again, no improvement in ( 12 performance or measurement capability results. ċ

To achieve HP-IB programming compatibility between 1980B's prefix 2131A- and below to those prefix 2142A- and above, order HP-IB kit, HP Part No. 01980-69506, and install. Operating anomalies existed in early instruments that required slight program changes to circumvent. Therefore, in some cases, old and new instruments cannot be controlled by the same program.

I/NS/WN

08/81-08

101 001 001



For more information, call your local HP Sales Office or nearest Regional Office: Eastern (301) 258-2000; Midwestern (312) 255-9800; Southern (404) 955-1500; Western (213) 877-1282; Canadian (416) 678-9430. Ask the operator for Instrument Sales. Or, Write: Hewlett-Packard, 1501 Page Mill Road, Palo Alto, CA 94304. In Europe: Hewlett-Packard S.A., 7, rue du Bois-du-Lan, P.O. Box CH-1217 Meyrin 2, Geneva, Switzerland. In Japan: Yokogawa-Hewlett-Packard Ltd., 29-21, Takaido-Higashi 3-chome, Suginami-ku, Tokyo, 168.

1980A/B-7