S E R V I C E N O T E

SUPERSEDES: NONE

4195A Network/Spectrum Analyzer

Serial Numbers:

0000J0000 / 2904J02155 0000A0000 / 2904A00209

Change a shield case when replacing A20 board

Duplicate Service Notes: None

To Be Performed By: Agilent-Qualified Personnel

Parts Required:

Part No. Qty. Description 04195-00811 1 Shield Case

Situation:

The part location of the A20 board was changed. The old shield case does not fit the new A20 board.

Solution/Action:

1. When the A20 board is defective and when being replaced with the new one, check the revision of the A20 board.

Continued

DATE: 03 September 1992

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
INFORMATION ONLY		
AUTHOR:	ENTITY:	ADDITIONAL INFORMATION:
MT	3355	

© 1992 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



Page 2 Service Note 4195A-13

2. If it's Rev. D or below (written as "D-xxxxx"), perform the next step. If it's Rev. E or above, replace the A20 board ONLY.

3. Replace the A20 board with the new one and the shield case with 04195-00811.