4396A-14A

S	Е	R	V		С	Е	N	0	Т	
							SUPERSED	ES: 4396	A-14	
439	6A Net	twork/	Spectr	um A	nalyze	r				
Seri	al Numb	ers: 324	1J00101	/ 3343J	IXXXXX	-				
Nev	v firmw	are co	rrects i	ncorr	ect GPI	B retur	n value of "	'TST?" o	query.	
To E	Be Perfor	med By	: Agilent-	-Qualif	ied Perso	onnel and	Customers*			
* If	the unit A	1 board	is PROM	1 versio	on, not cı	ıstomer-i	nstallable.			
Part	s Requir	ed:								
P/N			Qty.		Descri	ption				
0439	96-65211		1				llation Kit, 3.01			
0439	96-65212		1				llation Kit with	Flash ROI	Ms **	
5080)-3954				Revisi	on Label	, 03.01			
** T	This kit is for more d		with PRC	OM ver	sion A1	ooard. Re	efer to service n	ote 4396A	-01B	
f										
fe										
f										
f										
f										
fi										
f								C	Continued	

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:								
	MODIFICATION	RECOMMENDED						
ACTION CATEGORY:	 IMMEDIATELY ON SPECIFIED FAILURE AGREEABLE TIME 	STANDARDS: Labor 0.5 Hour						
LOCATION CATEGORY:	 CUSTOMER INSTALLABLE ON-SITE SERVICE CENTER 	SERVICE I RETURN USED RETURN INVENTORY: SCRAP PARTS: SCRAP SEE TEXT SEE TEXT						
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: October 1996						
AUTHOR: TN	ENTITY: 3355	ADDITIONAL INFORMATION:						

© 1995 AGILENT TECHNOLOGIES
PRINTED IN U.S.A.



Situation:

GPIB command "*TST?" query returns incorrect value on revision 1.xx and 2.xx.

Solution/Action:

Upgrading firmware revision to 3.02 fixes the bug. Refer to service note 4396A-01B for upgrade instruction.

NOTE

The firmware installation disk can be used for more than one unit. Then place an order for extra revision label.