S E R V I C E N O T E

SUPERSEDES: None

53181A Universal Counter

Serial Numbers: 53131A-01: 3416A06398 / 3416A08564

53132A-01: 3404A00742 / 3440A01124 53181A-01: 3418A00762 / 3418A00900

Unit powers up in the Standby mode.

Duplicate Service Notes: See Above

To Be Performed By: Agilent-Qualified Personnel

Parts Required:

P/N Description
53131-60002 Display Assembly

Situation:

When the unit's ON/Standby switch is in the Standby mode, some counters will automatically turn-on and will display a Self-Test failure. This is caused by the vendor process allowing moisture to be trapped under the solder mask.

Solution/Action:

Replace the display assembly with a new one from SMO/PCE.

Note: all expected "bad" assemblies have been purged from stock.

DATE: August 1996

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
MODIFICATION RECOMMENDED		
ACTION CATEGORY:	☐ IMMEDIATELY ☐ ON SPECIFIED FAILURE ☐ AGREEABLE TIME	STANDARDS: Labor 0.5 Hour
LOCATION CATEGORY:	☐ CUSTOMER INSTALLABLE☐ ON-SITE☐ SERVICE CENTER	SERVICE ☐ RETURN USED ☐ RETURN INVENTORY: ☐ SCRAP PARTS: ☐ SCRAP SEE TEXT ☐ SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL:
AUTHOR: JWE	ENTITY: 0200	ADDITIONAL INFORMATION:

© 1996 AGILENT TECHNOLOGIES PRINTED IN U.S.A.

