

S E R V I C E N O T E

SUPERSEDES: None

HP 54540C Oscilloscope

Serial Numbers: 0000A00000 / US99999999

When Power is cycled during an HPIB activity the Oscilloscope will lock up.**Duplicate Service Notes:**

54520C-04	54522C-04
54542A-03	54520A-03
54522A-03	54540A-03
54542C-04	

Situation:

If power is cycled while the instrument is performing operations over HPIB, the instrument will lock-up.

Solution/Action:

Power the instrument down, and while holding down any front panel key, power the instrument back up. This will clear the lock-up problem and allow normal operation of the instrument.

DATE: March 1997

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR:

TG

ENTITY:

0800

ADDITIONAL INFORMATION: