

S E R V I C E N O T E

SUPERSEDES: None

**5DX Structural Process Test Systems
Series II & Series 2L Systems**

Isolation Transformer Fuse Change

Serial Numbers: USXXXX200 / USXXXX375

To Be Performed By: Agilent-Qualified Personnel or Agilent Trained Customer

Situation:

A fuse protects the windings of the isolation transformer assembly (E7200-67991). A 3.0 Amp fast blow fuse (2110-1010) was used for this purpose. Due to nuisance openings on cold starts, the old 3.0 Amp fuse is being replaced with a 3.15 Amp slow blow fuse (2110-1074).

Solution / Action:

Customers with affected systems should purchase at least one new 3.15 Amp slow blow fuse for their consumables kit. The next time the isolation transformer fuse needs to be changed, it should be replaced with the new fuse.

DATE: February 2000

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
INFORMATION ONLY		
AUTHOR: TS	ENTITY:	ADDITIONAL INFORMATION:

