

S E R V I C E N O T E

SUPERSEDES: None

Agilent 5DX Structural Process Test Systems Series 2 and Series 3.

Serial Numbers: USXXXXXX300 / USXXXXXX650

Warning: Moving the Inner Barrier with the Access panels open can cause injury to people or damage equipment.

To Be Performed By: Agilent-Qualified Personnel or Agilent-Trained Customer

Parts Required:

Agilent P/N	Description	Quantity
N7200-68095	5DX INNER BARRIER SAFETY KIT	1

Situation:

The Inner Barrier can be moved with the Access panels open. This is a safety concern. It is possible to open or close the inner barrier and cause injury to people or damage equipment in its path.

Solution / Action:

Load the "5DX Inner Barrier Safety Patch" software onto the 5DX. After the "5DX Inner Barrier Safety Patch" has been loaded onto the 5DX, a warning dialog box will be displayed when the inner barrier is opened or closed from the Hardware Control Monitor. The 5DX warning will display "Warning: Crush Hazard: You are about to move the inner barrier, which could cause injury to the head or limbs or cause damage to equipment in its path. Please make sure the path is clear before continuing". The "5DX Inner Barrier Safety Patch" will be loaded by the customer. During the next PM, the CE will verify that the "5DX Inner Barrier Safety Patch" has been loaded.

DATE:

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
SAFETY			
ACTION CATEGORY:	<input type="checkbox"/> ON SPECIFIED FAILURE <input type="checkbox"/> AGREEABLE TIME	STANDARDS: .25 hours	LABOR
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input checked="" type="checkbox"/> ON-SITE <input type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY: <input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input checked="" type="checkbox"/> SEE TEXT	USED PARTS: <input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	ALWAYS	AGILENT RESPONSIBLE UNTIL : ALWAYS	
AUTHOR:GS	ENTITY:0980	ADDITIONAL INFORMATION:* See page 2	

ADDITIONAL INFO:

Verify "5DX Inner Barrier Safety Patch" has been loaded during the system's next PM.
If the "5DX Inner Barrier Safety Patch" needs to be loaded, download it from the member services web site:

<http://www.ate.agilent.com/emt/members/index.shtml>

If customer needs media order P/N N7200-68095 from ATLS. Parts and labor should be charged to warranty and reference FSN: 5DX-55-S on CSO.