70908A-21

S	Е	R	V	I	С	Е	Ν	0	Т	Е
							SUPERSEDE	S: None		
709	08A R	F Secti	ion							
Seri	al Numb	ers: 0000	0A00000	/ 9999	A99999					
Мо	dule Ve	rificatio	on Soft	ware	Modific	ation				
To E	Be Perfor	rmed By:	Agilent	Qualif	ied Perso	nnel or Cu	istomer			
Part Mod	s Requi lule Verif	red: fication Se	oftware p	oart nur	nber 709	08-10008	(Revision B.02	.00)		
Situ Whe to co these	ation: en perform onnect a j e test poi	ming the jumper be nts are lo	70908A I etween T cated.	Flatnes P4 and	s Calibra TP5. Thi	tion Test a s has led t	screen prompt to some confusi	instructs ion as to v	the user vhere	
								C	ontinued	
						I	DATE: 09 Dec	cember 1	992	

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:									
MODIFICATION RECOMMENDED									
ACTION CATEGORY:	 IMMEDIATELY ON SPECIFIED FAILURE AGREEABLE TIME 	STANDARDS: Labor 1.0 Hour							
LOCATION CATEGORY:	CUSTOMER INSTALLABLE	SERVICE I RETURN USED RETURN INVENTORY: SCRAP PARTS: SCRAP SEE TEXT SEE TEXT							
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: Product Support Life							
AUTHOR: RDS	ENTITY: 4500	ADDITIONAL INFORMATION:							

© 1992 AGILENT TECHNOLOGIES
PRINTED IN U.S.A.



Solution/Action:

Implement the following steps to change the software:

Insert Drivers Disk into your computer's default drive.

- 1. LOAD "DRIVERS 1"
- 2. ENTER or RETURN
- 3. REN 1,1
- 4. ENTER or RETURN
- 5. EDIT 4584
- 6. ENTER or RETURN
- Change line 4584 to read; Call Prompt_keys("CONTINUE",Key_pressed\$,"Connect a jumper between A12TP4 & A12TP5 (formerly W2) now, please.")
- 8. ENTER or RETURN
- 9. EDIT 4747
- 10. ENTER or RETURN
- Change line 4747 to read; Call Prompt_keys("CONTINUE",Key_pressed\$,"Remove jumper between A12TP4 & A12TP5 now, please.")
- 12. ENTER or RETURN
- 13. PURGE "DRIVERS_1"
- 14. ENTER or RETURN
- 15. STORE "DRIVERS_1"

Note: The write/protect switch on the disk needs to be in the write mode.

16. ENTER or RETURN