

S E R V I C E N O T E

SUPERSEDES: NONE

85629B Test and Adjustment Module

Serial Numbers: 0000A00000 / 9999A99999

Duplicate Service Note: 85629A-09

Considerations for performing external mixer amplitude adjustment**To Be Performed By:** Agilent-Qualified Personnel or Customer**Parts Required:** None**Situation:**

The External Mixer Amplitude Adjustment will fail or give incorrect results if the AVERAGE CNV LOSS and the CNV LOSS VS FREQ data are not set to the factory preset value of 30dB.

Solution/Action:

Before making the TAM External Mixer Amplitude Adjustment, make sure that the data for AVERAGE CNV LOSS and CNV LOSS VS FREQ are set to 30 dB.

DATE: 06 FEBRUARY 1992

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR: GPB	ENTITY: 5300	ADDITIONAL INFORMATION:
----------------	-----------------	-------------------------