S E R V I C E N O T E

SUPERSEDES: NONE

E3610A 30W Lab Bench DC Power Supply

Serial Numbers: KR41807594/KR64315031

To eliminate the oscillation from the power supply's output.

To be performed by: Agilent-Qualified Personnel

Duplicate Ser vice Notes E3611A-05

Situation:

The power supply's output shows an oscillation when either the (+) or (-) output terminal is connected to the ground terminal.

Solution / Action:

Remove the C4 and C5 capacitors on the main PC board.

DATE: March 1997

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
MODIFICATION RECOMMENDED		
ACTION CATEGORY:	■ IMMEDIATELY□ ON SPECIFIED FAILURE□ AGREEABLE TIME	STANDARDS: LABOR 1.0 Hours
LOCATION CATEGORY:	☐ CUSTOMER INSTALLABLE☐ ON-SITE☐ SERVICE CENTER	SERVICE ☐ RETURN USED ☐ RETURN PARTS: ☐ SCRAP SEE TEXT ☐ SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: March 1999
AUTHOR: NKP	ENTITY: Y300	ADDITIONAL INFORMATION:

© 1997 AGILENT TECHNOLOGIES PRINTED IN U.S.A.

