

MODIFICATION RECOMMENDED

**E8363B-02A**

**S E R V I C E N O T E**

Supersedes:  
E8363B-02

**E8363B Option 014 PNA Microwave Network Analyzers**

**Serial Numbers: ALL**

**A guard is available to protect the front-panel jumper cables during shipment.**

**Parts Required:**

<b>P/N</b>	<b>Description</b>	<b>Qty.</b>
E8361-00009	Guard, jumper cables	2

**ADMINISTRATIVE INFORMATION**

SERVICE NOTE CLASSIFICATION:			
<b>MODIFICATION RECOMMENDED</b>			
ACTION CATEGORY:	X AGREEABLE TIME	STANDARDS	LABOR: 0.25 Hours
LOCATION CATEGORY:	X CUSTOMER INSTALLABLE X ON-SITE X SERVICE CENTER X CHANNEL PARTNER	SERVICE INVENTORY: N/A	USED PARTS: N/A
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	NO CHARGE AVAILABLE UNTIL: END OF PRODUCT'S SUPPORT LIFE	
AUTHOR:	MF	PRODUCT LINE: WN	
ADDITIONAL INFORMATION: This Service Note applies to the following PNA models: E8361/3/4A Option 014, E8363/4B Option 014, E8363/4BH85 Option 014, E8361/3/4C Option 014, E8363/4CH85 Option 014, N5230A Options 425 & 525, and N5230C Options 425 & 525.			

© AGILENT TECHNOLOGIES, INC. 2009  
PRINTED IN U.S.A.

September 3, 2009

Rev. 16



**Situation:**

A guard is available to protect the front-panel jumper cables from being damaged during shipment.

**Solution/Action:**

Two guards should be installed to cover the front-panel jumper cables before the PNA is returned to the customer. The guards are identical, so either one can be used to cover the left or right-side jumper cables. The guards simply require a push-on installation, so no tools are necessary. To install, push each guard over the jumper cables until its cushioning material touches the front panel of the PNA.