J6804A-01 S E R V I C E N O T E

Supersedes: None

J6804A DNA HD

Serial Numbers:

MY48280102, MY48310101, MY48310102, MY48320106, MY48360101, MY48380101, MY48380102, MY48420101, MY48420102, MY48420103, MY48440101, MY48440103, MY48460101, MY48470107, MY48480103, MY48480109

The possibility exists that some of the instruments from the above table were shipped with a manufacturing defect of yet undetermined severity. This defect causes a RTSM failure issue in that some DNAs stop streaming RTSM data. When the failure occurs, a dialog box will appear with the message "Capture stopped. Cannot keep up with incoming data rate

Parts Required: P/N Description

Qty.

None


Situation:

Under normal operating conditions, if the DNA is connected to a system capable of handling Gigabit RTSM data, this failure message should not appear

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:	
INFORMATION ONLY	
AUTHOR: DM	PRODUCT LINE: 2J
ADDITIONAL INFORMATION:	

© AGILENT TECHNOLOGIES, INC. 2009 PRINTED IN U.S.A.





Solution/Action:

To obtain the Network Analyzer 6.10.102.001 software patch files, go to: http://analyzer.cos.agilent.com/updates. Download the PC Installer for the Network Analyzer.

To install/upgrade this software patch, follow these steps:

1. Unzip the na6.10.102.001patch.zip file to a convenient location on your PC.

2. Double-click the na6.10.102.001patch.exe file.

3. Start the Network Analyzer application and use Help | About to verify that your Network Analyzer software version is 6.10.102.001 when the installation has completed.