Information Only Service Note

Supersedes: NONE

N8731A DC System Power Supply

Serial Numbers: Refer to Table 1

The Problem – Units in the above serial number range may encounter missing serial number in WebUI and Keysight Connection Expert.

Parts Required: NONE

ADMINISTRATIVE INFORMATION

[]] Calibration Required[X] Calibration NOT Required

PRODUCT LINE: SP AUTHOR: LIM ZHAN MING

ADDITIONAL INFORMATION:



© Keysight Technologies 2015-2023 Information Only Service Note Version 1.3 | May 19, 2023| Page **1** of **3**

Situation:

Units in the above serial number range may encounter instrument unsecure store and result in missing serial number. The serial number will show "0" in WebUI and Keysight Connection Expert as shown in Figure 1 and Figure 2 respectively.

However, there is no impact on the functionality and specification of the instrument.



Figure 1: Serial number is "0" in WebUI



Figure 2: Serial number is "0" in Keysight Connection Expert

Solution/Action:

How to verify:

- 1. Turn on the instrument, connect it by using any of the interfaces.
- 2. Go to WebUI and Keysight Connection Expert to verify if the serial number is "0" as shown in Figure 1 and Figure 2 respectively.
- 3. Go to "Keysight Connection Expert" > "Interactive IO" > click "SYST:ERR?".
- 4. If error 208 prompts out, it means this instrument was not "secure stored".

How to fix:

- 1. Click on the link: <u>Secure Store Tool</u> to download the .exe file.
- 2. Run the "SecureStoreInitialization" fix tool.
- 3. Follow the instructions stated in the program.
- 4. The program will run for approx. 45 seconds.
- 5. Reboot your instrument after the process has completed.
- 6. Send "SYST:ERR?" to verify that "no errors" are reported.
- 7. Make sure WebUI and Keysight Connection Expert are showing the serial number.

Table 1: Affected Serial Number

US11M7584A	US23C4639S	US23C4647S
0011101/004/1	0020010000	0020010170

Revision History:

Date	Service Note Revision	Author	Reason for Change
19 th May 2023	01	LIM ZHAN MING	As Published