PRIORITY SAFETY - REQUIRES IMMEDIATE REPAIR ACTION AND SPECIAL EFFORT TO CONTACT CUSTOMERS

SP50-06-S SERVICE NOTE

Supersedes: SP50-10-S

Agilent SP50 1.0M (Series 0 and Series 1 Systems) Optical Board Test System

Serial Numbers: IE41180231 – IE42200102

POSSIBLE SERIOUS INJURY

WARNING

Pinch Hazard accessible through the side openings of the system

To Be Performed By: Agilent-Qualified Personnel Only

Parts Required:
P/NDescriptionQty.5186-5436SJ safety upgrade kit1

ADMINISTRATIVE INFORMATION

| SERVICE NOTE CLASSIFICATION: | | | |
|--|----------------|--------------------------------|----------------------|
| PRIORITY SAFETY | | | |
| ACTION CATEGORY: | IMMEDIATELY | STANDARDS: LABOR: 1.0 Hours | |
| LOCATION CATEGORY: | ON-SITE | SERVICE INVENTORY: SCRAP | USED PARTS: SCRAP |
| AVAILABILITY: | End Of Support | | |
| AUTHOR: Martin Boyce PRODUCT LINE: 80 | | | |
| ADDITIONAL INFORMATION: 5186-5436 is orderable through SPD (SERVICE PARTS DELIVERY) at 1-800-816-8650. | | | |
| Reference the service note number in the activity description field of the SR. | | | |
| © AGILENT TECHNOLOGIES, INC. 2005 | | | |
| PRINTED IN U.S.A. | | | |

March 26, 2005



Situation:

If the SP50 has power applied and service personnel or operators access the inside of the system through the side openings, their hand can be caught in the Gantry, causing severe injury.

Solution/Action:

To install Safety Guards to protect against potential pinch hazard points on the SP50 system.

To install the gantry safety guard kits and follow the Installation Procedure 5186-5438 included in the "Safety Guard Kit" 5186-5436.

Note:

Once you have completed the installation of the "Safety Upgrade Kit" fill out and install the Service Note label (Part Number N7200-84366) on the SP50 System near the serial number plate at the rear of the machine.

After completion of this Service Note send an email with the SP50 Serial number and state the Service Note Identification Number to: <u>MTBUSERVICENOTES@agilent.com</u>