33622A-03

Modification Recommended Service Note

Supersedes: NONE

33622A Function Generator

Serial Numbers: MY00000000 to MY53801606

The Problem – Customers have reported that when power is applied to the instrument but the instrument NOT turned on ("Standby Mode"), **some** instruments will emit an audible high-pitched whistle or whine. To fix this, the existing power supply must be replaced with the newer power supply, as detailed in the solution below.

Parts Required:				
P/N	Description			
5041-5256	Power Supply AC-DC Switching 100 Watt 1-Output 24V 4.2A			

ADMINISTRATIVE INFORMATION

ACTION CATEGORY:	X ON SPECIFIED FAILURE [[]] AGREEABLE TIME	STANDARDS LABOR: 2 Hours
LOCATION CATEGORY:	 []] CUSTOMER INSTALLABLE []] ON-SITE (active On-site contract required) X SERVICE CENTER []] CHANNEL PARTNERS 	SERVICE: [[]] RETURN USED [[]] RETURN INVENTORY: [[]] SCRAP PARTS: [[]] SCRAP [[]] SEE TEXT [[]] SEE TEXT
AVAILABILITY: PRODUCT'S SUPPORT LIFE		NO CHARGE AVAILABLE UNTIL: January 1, 2018
	X Calibration Required [[]] Calibration NOT Required	PRODUCT LINE: GM AUTHOR: MDB

ADDITIONAL INFORMATION:



Qty

Situation:

To satisfy customers who complain about the audible high-pitched whistle or whine from the 33622A in Standby mode, we will replace the power supply free of charge until the end of January, 2018. This is not a recall, and will only be done when a customer complains about the noise in Standby mode.

If the unit in question proves to be "No Trouble Found", it will be returned to the customer as is.

Solution/Action:

The solution is to replace the old power supply with a new one. The new power supplies have a Serial Number of K1538xxxx or higher.



The procedure for replacing the power supply module is shown below.

The power supply is accessed by removing the back cover and sliding out the surrounding metal wraparound cover.



Disconnect the power input and output connectors and remove the four screws holding the power supply to the swing out panel.

Take the Power Supply (5041-5256) out of the Power Supply Shield (5041-5252).



Assemble the new Power Supply into the Power Supply Shield by sliding the power supply into the shield. Note the orientation of the power supply needs to be correct, where the highlighted capacitor needs to be clearly visible.





Assemble the Power Supply Shield with the Power Supply in it to the Power Supply Deck as shown. Make sure the orientation of the powers supply is correct. Secure the four screws (0515-0430) to the Power Supply Deck by using T10 Torx as shown below.



Connect Power Supply Cable (5041-5251) to the Power Supply and the PCB Main Board Assembly.



Re-attach the line power connectors, being careful to get the orientation of the connectors correct.



Check the Function Generator with power applied but not turned on (Standby Mode) to verify no highpitched noise is present.

Revision History:

Date	Service Note Revision	Author	Reason for Change
30 Dec 2106	01	MDB	As Published