4987A-02

S	Е	R	V	Ι	С	Е	Ν	0	Т	Е
	SUPERSEDES: None									
4	4987A Ethernet LanProbe									
S	Serial Numbers: US34380000/US34389999 Modification applies to all 4987A's									
F	Firmware download failure results with Debug prompt									
D	Duplicate Service Notes: 4986A-06									
Т	To Be Performed By: Customer, or Agilent-Qualified Personnel									
Р	Parts Required:									
A Terminal or a PC emulating a Terminal (Using Windows Terminal or Hyperterminal applet). The following RS-232 (Crossover or null modem) cables.										
P	/N		Desc	ription	l					
24 N	4542G on Agiler	nt	RS-2 9-pii	232 9-p n male 1	in female to 9-pin r	e to 25-pir nale Genc	n male ler Changer			
Si	ituation:									
Fi	Firmware download failure results with the 4987A booting to the Debug prompt.									
									Contin	ued
	DATE: March 1999									

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICA	TION:								
INFORMATION ONLY									
AUTHOR:	ENTITY:	ADDITIONAL INFORMATION:							
DTH	0801								
© 1999 AGILENT TEC PRINTED IN U.S.A.	HNOLOGIES	Agilent Technologies							

Example 4987A output shown below.

POST...

Timer0/Refresh Counter: testing...Okay SCC Polling: testing...Okay DRAM Lower 1 Meg: testing...Okay 512K Flash Found 4M DRAM Found 128K BRAM Found Upper DRAM: testing...Okay RTC NVRAM: testing...Okay RTC Clock: testing...Okay BRAM: testing... BRAM: testing... BRAM: testing...Okay Timer0/Slicer: testing...Okay Timer1: testing...Okay LAN Controller: testing...Okay SCC Interrupts: testing...Okay Watchdog: testing...Okay Application Header Not Found.

=>

Solution / Action:

The 4987A firmware must be restored to Flash using XMODEM. Use the following procedures to download the firmware.

1. Obtain and copy the the current firmware file to a floppy, or to a directory on the pc.

The firmware may be retrieved by FTP from the col.agilent.com (15.255.240.16) server in the directories:/dist/netmetrix/lpfirmware/ rmon1. Please refer to the readme file contained in this directory for current firmware version, special notes, and checksum information.

- 2. Connect a terminal (or a PC emulating a terminal) Com1 or Com2 port to the LanProbe RS-232C port using an RS-232 crossover or null-modem cable.
- 3. Configure the terminal:

Using the Windows Terminal Program_

- a. Open the Windows Terminal Program.
- b. From the Terminal Menu; Select Settings, Communications.
- c. Configure the Terminal for;

Baud Rate - 9600 Data Bits - 8 Stop Bits - 1 Parity - None Flow Control - Xon/Xoff Connector - Com1 or Com2 (Com port for connection to LanProbe)

Using the Windows HyperTerminal Program

- a. Open the Windows HyperTerminal Program. From the Windows Start menu. Select Programs, Accessories, HyperTerminal.
- b. Double-click the HyperTrm icon.
- c. Select "Cancel" to close the Connection Description window.
- d. From the New Connection HyperTerminal window. Select File, Properties. The New Connections Properties window will be displayed.
- e. In the Phone Number section. Use the down arrow to change the "Connect Using" setting to com1 or com2 (com port for RS-232C cable connection to the LanProbe).
- f. Select "Configure...".

Configure Port Settings to; Bits per second - 9600 Data bits - 8 Parity - None Stop Bits - 1 Flow Control - Xon/Xoff

- g. Select "OK".
- 4. Connect the power cord to apply power to the LanProbe
- 5. Erase the Flash. At the Debug prompt =>. Type ef and then press the "Enter" key.

Example;

=>ef (Enter)

The text "Erase Flash: Programming Zeros..." will be displayed. When the Flash is completely erased, the text "Erase Flash: Programming Zeros...Erasing...Done." will be displayed.

6. Change the 4987A baud rate to 9600. At the Debug prompt =>. Type ba 9600 and then press the "Enter" key.

Example;

=>ba 9600 (Enter)

7. Download to Flash. At the Debug prompt =>. Type df and then press the "Enter" key.

Example;

=>df (Enter)

The text "Downloading to Flash: Receiving File..." will be displayed.

8. Transfer the firmware file.

Using the Windows Terminal Program_

- a. From the Terminal menu; Select Transfers, Send Binary files. .The "Send Binary File" window will open.
- b. Select the firmware filename from its file location/directory and press "Okay." The firmware file will be transfered to the LanProbe.

Caution! Do not remove power from the 4987A.

c. Continue to step 9.

Using the Windows HyperTerminal Program

- a. From the "New Connection HyperTerminal" menu; Select Transfer.
- b. In the "Send File" window; Select the firmware filename from its file location/directory.
- c. Use the down arrow to change the Protocol to XMODEM.
- d. Select "Send". The "Xmodem file send" window will be displayed. The firmware file will be transfered to the LanProbe.

Caution! Do not remove power from the 4987A.

- e. Continue to step 9.
- When the firmware download is finished. The following text will be displayed. "Receive File Complete." "Programming Flash...Complete."
- 10. Reset the probe and exit the Debugger. At the Debug prompt =>. Type rs and then press the "Enter" key.

Example;

=>rs (Enter)

The 4987A will reboot and display the Power-On Self Test (POST). The Application will load and the 4987A banner will be displayed.

Example 4987A output shown below.

512K Flash Found 4M DRAM Found 128K BRAM Found Upper DRAM: testing...Okay RTC NVRAM: testing...Okay RTC Clock: testing...Okay BRAM: testing... BRAM: testing...Okay Timer0/Slicer: testing...Okay Timer1: testing...Okay LAN Controller: testing...Okay SCC Interrupts: testing...Okay Watchdog: testing...Okay Application Header Found. Checksum...Okay. Copying Application ROM to RAM...Done Jumping to Application...

POST completed successfully. Node Locator II successfully loaded LanProbe III Ver. A.01.02, (Boot ROM A.00.01 4M) IEEE 802.3/Ethernet, Network Monitor, MIB-II, RMON (c) Copyright 1991-1995 by Agilent Technologies (c) Copyright 1988, 1989 by Carnegie Mellon University >

11. Firmware download is complete. Remove power from the 4987A