



After the program is loaded, "select code ?" will appear on the 9825A display. Enter 7XX and press  , "XX" being the 5345A HP-IB address. The 5345A HP-IB address entered must be even. Odd addresses are for Computer Dump mode.

When the correct 5345A address code is entered, the counter performs its first set of tests. The program will stop at the conclusion of each test. At this time, the operator verifies that the action programmed by the 9825A has occurred. To advance to the next test, simply press  . If it is desired to repeat a test, set the variable L to 1 via the keyboard (type 1→L  ). Then enter the number of the test to be repeated by typing cont "#"  . For example, to repeat test number 5, type 1→L  cont "5"  . Test 5 will repeat each time  is pushed. To advance to the next test (to step 6 in the example), turn L to 0 when the program stops (type 0→L  ) and push  .

Step	Test	Description
1	GATE TIME	The first test sets the 5345A to remote (RMT light on) and measures the frequency of the internal 100 MHz check signal. The program varies the gate times from 1 SEC to MIN and checks for a decreasing number of displayed digits. If an incorrect number of digits is displayed and output to the calculator, "ERROR" is printed by the calculator printer. The calculator displays the current gate time as the test progresses. The test is finished when "MIN" is displayed in the calculator display. Push <b>CONTINUE</b> to advance to Step 2.
2	FUNCTION SWITCH	The counter is put in check and the function switch is remotely programmed in the following order: PLUG-IN, FREQ A, PERIOD A, RATIO B/A, TIME INT A TO B, START, and STOP. The operator should visually confirm that the counter's display matches the readout called for on the calculator's display. Push <b>CONTINUE</b> after each condition.
3	FREQ MULTIPLIER SUFFIX	This test checks the display multiplier suffix selection for frequency mode. This function, which cannot be selected by the front panel switches, allows the user to force the counter to display in a format (i.e., MHz, kHz, Hz, etc.) selected by the user instead of what the counter would normally display. The test programs the counter to display the 100 MHz check signal in terms of mHz, Hz, kHz, MHz, and GHz. The calculator display shows what the counter should display at each point. This test is completely automatic in that the calculator checks for the appropriate number of digits in the displayed answer. The operator should visually confirm operation of the suffix lights in the counter annunciator display. Push <b>CONTINUE</b> to advance to Test 4.
4	DECIMAL POINT	The display position may be remotely programmed. When operated in the AUTO mode, the display is positioned with the least significant digit in the rightmost display position. In this test, the .1 GHz check signal is measured and the display position is varied. The program automatically checks for the correct display. Push <b>CONTINUE</b> to advance to Test 5.
5	PERIOD MULTIPLIER	This test checks the display multiplier suffix selection for Period/Time Interval mode. The counter is programmed to display the period of the 100 MHz check signal in terms of ks, s, ms, $\mu$ s, and ns. The calculator display shows what the counter should display at each point. This test is completely automatic in that the calculator checks for the appropriate number of digits in the displayed answer. The operator should visually confirm operation of the suffix lights in the counter annunciator display. Push <b>CONTINUE</b> to advance to Test 6.
6	INT/EXT GATE	This checks the operation of Internal/External Gate selection (a rear panel switch does the selection in the manual mode). For EXT GATE, the counter should display 0000000000 since no external gate signal is present. Push <b>CONTINUE</b> for INT GATE; the counter should display the 100.00000 MHz check signal. Push <b>CONTINUE</b> to advance to Test 7.

Step	Test	Description
7	SAMPLE RATE	<p>This test first programs the counter for a minimum display time and then returns it to the normal sample rate. These functions are not selectable from the panel switches. In MIN DISPLAY TIME, the counter effectively bypasses the sample rate control portion of the measurement cycle, allowing measurements to be taken every 1 to 5 ms. In this mode the counter display will be blank or consist of 1 digit. The gate light on the counter annunciator display should be on. Push <b>CONTINUE</b> to select the normal sample rate mode which returns the counter to making measurements with 50 ms between samples. After verifying proper operation for each condition, push <b>CONTINUE</b> to advance to Test 8.</p>
8	HOLD	<p>This test checks another aspect of the sample rate control. When the counter is programmed to "HOLD", the counter displays all zeros and all gating is stopped. When the <b>CONTINUE</b> key is pressed, the counter is instructed to make one measurement. The "GATE" light on the counter annunciator display should momentarily light, indicating that the gate was opened. Press <b>CONTINUE</b> three times to make three measurements. The counter is then taken out of HOLD and the "GATE" light will flicker, indicating continual measurements and updating of the display. The calculator will display "NOT HOLD" for this condition. Push <b>CONTINUE</b> to proceed to Test 9.</p>
9	ACCUMULATE	<p>This test checks the operation of the ACCUMULATE A+B and ACCUMULATE A-B modes of operation (rear panel switch). The counter is placed in START and counts the check signal. Since the counter is in START and CHECK, the 100 MHz check signal is counted by both the event scaler (register) and time scaler (register). The display shows the sum of these two registers A+B.</p> <p>Push <b>CONTINUE</b> and the counter is placed in STOP and A-B. The counter displays the difference of these two registers (should be 0).</p> <p>Push <b>CONTINUE</b> after visual verification of proper operation.</p>
10	OUTPUT	<p>This test checks the operation of the output modes "WAIT until addressed" and "ONLY IF addressed". In the "WAIT until addressed" output mode, the counter waits in the output phase of the measurement cycle until a command to output is received. Consequently, the display cycle is not entered and the counter display will be blank. Push <b>CONTINUE</b> to select the "ONLY IF addressed" mode. In this mode, the output phase of the measurement cycle is bypassed until an output command is received. Hence, the display cycle is entered after each measurement and the counter display continues (START, A+B mode). Pushing <b>CONTINUE</b> causes the counter to output the current reading to the calculator which display the reading. The two displays should agree. Push <b>CONTINUE</b> and the calculator causes the counter to make and output 10 readings, each one momentarily displayed on the calculator. The last reading is held in both displays. Push <b>CONTINUE</b> and END OF TEST will be displayed.</p> <p>To repeat the program push <b>RUN</b>.</p>

## SAMPLE PRINTOUT

5345A HP-IB Test

## 1-GATE TIME TEST

Each GATE TIME  
code is  
automatically  
sent to 5345A.  
Check Mode set.  
Output verified.

## 2-FUNCTION TEST

Plus-in  
Frequency  
Period  
Ratio  
Time Interval  
Start  
Stop

## 3-FREQ MULT

## SUFFIX TEST

Function=Freq.  
Each MULT SUFFIX  
is automatically  
sent to 5345A  
Check mode set.  
Output verified  
and displayed  
on the 9825A.

4-DECIMAL POINT  
TEST (FREQ MODE)

Each DISPLAY  
POSITION code  
is automatically  
sent to 5345A  
Check mode set.  
9825A shows  
position of  
the dec point  
digit 10 on left  
digit 0 on right

## 5-PERIOD MULT

## SUFFIX TEST

Function=Period.  
Each MULT SUFFIX  
is automatically  
sent to 5345A.  
Check mode set.  
Output verified  
and displayed  
on the 9825A.

6-INT/EXT GATE  
TEST

External Gate  
Internal Gate

7-SAMPLE RATE  
TEST

Sample rate  
control  
bypassed.  
Max Sample Rate

## 8-HOLD TEST

HOLD sent to  
5345A. Send  
Sample Trigger  
Command each  
time CONTINUE  
is pressed.  
Sample count is  
displayed on 9825A.

9-ACCUMULATE  
TEST

A+B code sent  
A-B code sent

## 10-OUTPUT TEST

Wait 'til addressd  
Only if addressd  
\*Takes 1 reading.  
\*Stops. When  
\*CONTINUE is  
\*pressed, takes  
\*10 more readings  
\*and displays  
\*them on 9825A.  
\*Stops and  
\*displays the  
\*11th reading.

END OF TEST

## PROGRAM LISTING

```

0: dsp "5345A Verification Test";prt "5345A HP-IB Test"
1: prt "-----";spc 2
2: "code":ert "select code?";S
3: if S=721;dsp "ERROR";wait 1000
4: if S=721;dsp "calculator address=computer dump";wait 2500;gto "code"
5: if S>730;dsp "out of address range-high";wait 1000;gto "code"
6: if S<700;dsp "out of address range-low";wait 1000;gto "code"
7: if Smod2=1;dsp "odd address-computer dump";wait 2000;gto "code"
8: dim C$(40);dev "ctr",S
9: "1":prt "1-GATE TIME TEST","each GATE TIME","code is","automatically"
10: prt "sent to 5345A.,""Check Mode set.,""Output verified.";spc 2
11: prt "ctr","I2E8?I1"
12: 9→A;gsb "ECHK"
13: dsp "1 SEC GATE";beep;wait 3000
14: wrt "ctr","G?I1";8→A;gsb "ECHK"
15: dsp "100 MSEC GATE";beep;wait 2000
16: wrt "ctr","G>I1";7→A;gsb "ECHK"
17: dsp "10 MSEC GATE";beep;wait 1000
18: wrt "ctr","G=I1";6→A;gsb "ECHK"
19: dsp "1 MSEC GATE";beep;wait 1000
20: wrt "ctr","G<I1";5→A;gsb "ECHK"
21: dsp "100 USEC GATE";beep;wait 1000
22: wrt "ctr","G;I1";4→A;gsb "ECHK"
23: dsp "10 USEC GATE";beep;wait 1000
24: wrt "ctr","G:I1";3→A;gsb "ECHK"
25: dsp "1 USEC GATE";beep;wait 1000
26: wrt "ctr","G9I1";2→A;gsb "ECHK"
27: dsp "100 NSEC GATE";beep;wait 1000
28: wrt "ctr","G5I1";1→A;gsb "ECHK"
29: dsp "MIN GATE-Press CONTINUE";stp
30: if L=1;gto "1"
31: "2":prt "2-FUNCTION TEST";wrt "ctr","I2E8?G?F2I1"
32: prt "Plug-in"
33: dsp "Verify 5345A dsply: 00000000000";stp
34: wrt "ctr","F0I1";le8→A;gsb "READ"
35: prt "Frequency"
36: dsp "Verify 5345A: 100.00000 MHz";stp
37: wrt "ctr","F1I1";le-8→A;gsb "READ"
38: prt "Period"
39: dsp "Verify 5345A: 10.000000 nSEC";stp
40: wrt "ctr","F5I1";1→A;gsb "READ"
41: prt "Ratio"
42: dsp "Verify 5345A: 1.0000000";stp
43: wrt "ctr","F3I1";prt "Time Interval"
44: dsp "Verify 5345A: 10.000000 nSEC";stp
45: wrt "ctr","F4I1";prt "Start"

```

## PROGRAM LISTING (Continued)

```

46: dsp "Verify 5345A: Accumulating";sto
47: wrt "ctr", "F6";prt "Stop";spc 2
48: dsp "Verify 5345A: Stopped acc'ltng";sto
49: if L=1;gto "2"
50: "3":prt "3-FREQ MULT", "SUFFIX TEST", "function=Frec."
51: prt "Each MULT SUFFIX", "is automatically", "sent to 5345A"
52: prt "Check mode set.", "Output verified", "and displayed"
53: prt "on the 9825A.";snc 2
54: wrt "ctr", "I2G?D;C3E?E8I1";11→A;gsb "PCHK"
55: dsp "00000000000.MHZ*";beep;wait 3000
56: wrt "ctr", "C4I1";9→A;gsb "PCHK"
57: dsp "100000000.HZ*";beep;wait 3000
58: wrt "ctr", "C5";6→A;gsb "PCHK"
59: dsp "100000.KHZ*";beep;wait 3000
60: wrt "ctr", "C6";3→A;gsb "PCHK"
61: dsp "100.MHZ";beep;wait 3000
62: wrt "ctr", "C500C7";0→A;gsb "PCHK"
63: dsp ".1 GHZ--Press CONTINUE";beep;sto
64: if L=1;gto "3"
65: "4":prt "4-DECIMAL POINT", "TEST (FREQ MODE)"
66: prt "Each DISPLAY", "POSITION code", "is automatically"
67: prt "sent to 5345A", "Check mode set.", "9825A shows"
68: prt "position of", "the dec point", "digit 10 on left"
69: prt "digit 0 on right";spc 2
70: wrt "ctr", "I2G5E8?C7D1";10→A;fxd 0
71: gsb "PCHK"
72: beep;dsp "5345A digit # ";A;wait 1000
73: wrt "ctr", "D2";9→A;gsb "ECHK"
74: beep;dsp "5345A digit # ";A;wait 1000
75: wrt "ctr", "D3";8→A;gsb "ECHK"
76: beep;dsp "5345A digit # ";A;wait 1000
77: wrt "ctr", "D4";7→A;gsb "ECHK"
78: beep;dsp "5345A digit # ";A;wait 1000
79: wrt "ctr", "D5";6→A;gsb "ECHK"
80: beep;dsp "5345A digit # ";A;wait 1000;wrt "ctr", "D6";5→A;gsb "ECHK"
81: beep;dsp "5345A digit # ";A;wait 1000;wrt "ctr", "D7";4→A;gsb "ECHK"
82: beep;dsp "5345A digit # ";A;wait 1000;wrt "ctr", "D8";3→A;gsb "ECHK"
83: beep;dsp "5345A digit # ";A;wait 1000;wrt "ctr", "D9";2→A;gsb "ECHK"
84: beep;dsp "5345A digit # ";A;wait 1000;wrt "ctr", "D0";1→A;gsb "ECHK"
85: beep;dsp "5345A digit # ";A;wait 1000;wrt "ctr", "D:";0→A;gsb "ECHK"
86: beep;dsp "5345A digit # ";A,"--PRESS CONT";sto
87: wrt "ctr", "D0"
88: if L=1;gto "4"
89: "5":prt "5-PERIOD MULT", "SUFFIX TEST"
90: prt "Function=Period.", "Each MULT SUFFIX", "is automatically"
91: prt "sent to 5345A.", "Check mode set.", "Output verified"

```

## PROGRAM LISTING (Continued)

```

92: prt "and displayed", "on the #825A."; spc 2
93: wrt "ctr", "I2F1G?D1C3E?I1"; 10→A; gsb "ECHK"
94: dsp ".0000000000KSEC*"; beep; wait 2000
95: wrt "ctr", "C4I1"; 7→A; gsb "LCHK"
96: dsp ".0000000100SEC"; beep; wait 2000
97: wrt "ctr", "C5I1"; 4→A; gsb "LCHK"
98: dsp ".0000100000MSEC"; beep; wait 2000
99: wrt "ctr", "C6I1"; 1→A; gsb "LCHK"
100: dsp ".0100000000USEC"; beep; wait 2000
101: wrt "ctr", "C7D3I1"; 2→A; gsb "PCHK"
102: dsp "10.000000 NSEC--Press CONTINUE"; beep; stp
103: if L=1; gto "5"
104: "6": spc 1; prt "6-INT/EXT GATE", " TEST"
105: wrt "ctr", "I2E8?G?E; I1"; 0→A
106: prt "External Gate"
107: dsp "Verify 5345A: 0000000000"; stp
108: wrt "ctr", "E3"; 1e8→A; gsb "READ"
109: prt "Internal Gate"; spc 2
110: dsp "Vrify 5345A: 100.00000 MHz Gating"; stp
111: if L=1; gto "6"
112: "7": prt "7-SAMPLE RATE ", " TEST"
113: wrt "ctr", "I2G?E?E?"; prt "Sample rate", " control", " bypassed."
114: dsp "Verify 5345A: Blank Hz & GATE"; stp
115: wrt "ctr", "E4"; prt "Max Sample Rate"; spc 2
116: dsp "Vrify 5345A: 100.00 MHz Gating"; stp
117: if L=1; gto "7"
118: "8": prt "8-HOLD TEST"
119: prt "HOLD sent to", "5345A. Send", "Sample trigger", "Command each
120: prt "time CONTINUE", "is pressed. ", "Sample count is", "dsplyd on #825A
121: spc 2
122: wrt "ctr", "I2E8?G?E?I1"
123: dsp "5345A: 0000000000 No GATE"; stp
124: wrt "ctr", "J1"; beep; dsp "SAMPLE 1--Press CONTINUE"; stp
125: wrt "ctr", "J1"; beep; dsp "SAMPLE 2--Press CONTINUE"; stp
126: wrt "ctr", "J1"; beep; dsp "SAMPLE 3--Press CONTINUE"; stp
127: wrt "ctr", "E1"; dsp "NOT HOLD--Verify 5345A: gating"; stp
128: if L=1; gto "8"
129: "9": spc 1; prt "9-ACCUMULATE", " TEST"
130: wrt "ctr", "I2F?E8?I=I?I1"
131: prt "A+B code sent"
132: dsp "Verify 5345A: Accumulating"; stp
133: wrt "ctr", "F6E75"; 0→A; gsb "READ"
134: prt "A-B code sent"; spc 2
135: dsp "Verify 5345A: 0000000000"; stp
136: if L=1; gto "9"
137: "10": prt "10-OUTPUT TEST"; wrt "ctr", "I2?4E?E: 15G?I1"
138: prt "wait 'til addrsd"
139: dsp "Verify 5345A: Blank & GATE"; stp
140: wrt "ctr", "E2I1"; prt "Only if addrsd"

```



## PROGRAM LISTING (Continued)

```
141: dsp "Verify 5345A: accumulating";stp
142: prt "*Takes 1 reading.", "*Stops. When, "*CONTINUE is", "*pressed, takes
143: prt "*10 more readings", "*and displays", "*them on 9825A.", "*Stops and"
144: prt "*displays the", "*11th reading.";scc 2
145: wrt "ctr", "8F6";red "ctr",A;cmd 7, "_";fxd 0
146: dsp "Verify 5345A:",A;stp
147: wrt "ctr", "12E8?F411";0+X
148: wait 1000;wrt "ctr", "86";red "ctr",A;cmd 7, "_";dsp A;beep
149: wait 1000;if (X+1+X)>9;gto +2
150: wrt "ctr", "84";gto -2
151: fxd 0;dsp "Verify 5345A:",A;sto
152: scc 2;prt "END OF TEST";dsp "END";scc 4;stp
153: "ECHK":wait 50;6+R;-2+C
154: gsb "CNT"
155: wrt "ctr", "11"
156: ret
157: "PCHK":wait 50;46+R;-1+C
158: gsb "CNT"
159: wrt "ctr", "11"
160: ret
161: "LCHK":wait 50;49+R;-2+C
162: gsb "CNT"
163: wrt "ctr", "11"
164: ret
165: "CNT":rdb("ctr")>B
166: if B=R;gto +2
167: C+1+C;gto -2
168: if A#C;prt "ERROR C=",C,A
169: ret
170: "READ":wait 50;red "ctr",C;red "ctr",C
171: if A#C;prt "ERROR"
172: wrt "ctr", "11"
173: ret
174: end
*6378
```

