N9030B-09

Information Only Service Note

Supersedes: [NONE]

N9030B PXA Signal Analyzer

Serial Numbers: ALL

Selecting Proper CPU Replacement Part Number

The standard CPU used in the N9030B PXA has changed since the product was introduced. The current standard CPU looks like earlier CPUs. Replacing the CPU with the proper part number will ensure that the analyzer is returned to the end-user with the same performancelevel CPU as was installed in the analyzer prior to the repair.

Parts Required: Refer to Solution / Action below

ADMINISTRATIVE INFORMATION

[]] Calibration Required X Calibration NOT Required PRODUCT LINE: 12 AUTHOR: BDT

ADDITIONAL INFORMATION:



© Keysight Technologies 2015-2024 Information Only Service Note Version 1.3 | June 4, 2024| Page 1 of 4

Situation:

The standard CPU used in the N9030B PXA has changed since the product was introduced. The current standard CPU looks very similar to the earlier CPUs. Replacing the CPU with the proper part number will ensure that the analyzer is returned to the end-user with the same performance-level CPU as was installed in the analyzer prior to the repair.

There are <u>three CPU</u> replacement assemblies available:

- N9020-60247
 KIT, OPTION PC6/PC6S PROCESSOR BOARD REPLACEMENT
 - W1312-60524 CPU Module, Core i7-9850HL, 32GB RAM no HDD
- W1312-60561 CPU Module, Core i7 9850HE, 32GB RAM no HDD

Solution/Action:

There are several methods to determine what the currently installed CPU type is depending upon whether or not the CPU is functional and whether or not the X-Series Signal Analyzer measurement application is running.

NOTE: The recommended CPU replacements listed in this service note should not be used to upgrade from one type of CPU to another. The N9094BU Windows Operating System and PC Processor / Drive Upgrade is available to obtain the latest CPU and operating systems. Refer also to http://www.keysight.com/find/PXA_upgrades for more information.

Method 1: If CPU is functional, but X-Series SA Measurement Application is not Running

If the CPU is functional to the point that it can display the Windows Desktop, connect a mouse to the analyzer and click Start. Right-click My Computer and select Properties. Look at the text following "Manufactured and Supported by:" Select the appropriate CPU replacement part number based upon the Properties of My Computer as shown in Table 1 below.

Table 1. CPU Identification Based Upon Properties of My Computer

Properties of My Computer	CPU Replacement Part Number
<u>Intel ® Core ™ i7-3615QE CPU @ 2.30 GHz</u>	<u>N9020-60247</u>
<u>Intel ® Core ™ i7-9850HL CPU @ 1.90_GHz</u>	W1312-60524
Intel® Core™ i7 CPU 9850HE @2.70 GHz	W1312-60561

Method 2: If X-Series SA Measurement Application is Running

If the X-Series SA Measurement Application is running, press System, Show, System. Note the Instrument SW Revision. One of the first two entries in the Options list should identify the type of CPU installed. The CPU option will be N9030B-PC6, N9030B-PC6S, N9030B-PC8, or N9030B-PCA. Select the appropriate CPU replacement part number based upon the CPU Option and the Instrument SW Revision as shown in Table 2 below.

Table 2. CPU Identification Based Upon CPU Option and Instrument SW Revision

CPU Option	Instrument SW Revision	CPU Replacement Part Number
N9030B-PC6 <u>Intel ® Core ™ i7-3615QE CPU @ 2.30 GHz. 16</u> <u>GB</u>	>= A.16.05	N9020-60247
<u>N9030B-PC6S_Intel ® Core ™ i7-3615QE CPU @ 2.30_GHz, 16</u> <u>GB</u>	<u>>= A.25.08</u>	<u>N9020-60247</u>
N9030B-PC8 <u>Intel ® Core ™ i7-9850HL CPU @ 1.90, 32 GB</u>	Any	W1312-60524
N9030B-PCA Intel® Core™ i7 CPU 9850HE @2.70 GHz, 32 GB	Any	W1312-60561

NOTE: The CPU replacement part number N9020-60247 is the same for both N9030B-PC6 and N9030B-PC6S. The CPU will be the N9030B-PC6S CPU but will identify as a PC6 if the instrument SW revision is <A.25.08. Functionally, the only difference between the PC6 and PC6S is the that the PC6S includes internal cal memory (referred to as Internal Flash in the Alignment Data Wizard).

Method 3: If CPU is Not Functional

If the CPU is not functional, it will be necessary to determine the installed CPU based upon the part number of the currently installed CPU.

Start with the CPU installed in the PXA. View the CPU from the rear panel of the PXA. The CPU part number, which will begin with "W1312", should appear on a label near the LAN connector. Select the appropriate CPU replacement part number based upon the CPU part number as shown in Table 3 below.

CPU Part Number	J Part Number CPU	
	Replacement	
	Part Number	
W1312-60141	N9020-60247	
W1312-60212	N9020-60247	
W1312-60214	N9020-60247	
W1312-60524	W1312-60524	
W1312-60561	W1312-60561	

Table 3. CPU Identification Based Upon CPU Part Number

Revision History:

Date	Service Note Revision	Author	Reason for Change
29 May 2024	01	Brian Torr	As Published