MODIFICATION RECOMMENDED

34405A-07

S E R V I C E N O T E

Supersedes: None

34405A Digital Multimeter, 5.5 digit

Serial Numbers: MY53019072 to MY53450092, MY52139093, MY52220028, MY52290004, MY52330016, MY52360033, MY52440022, MY52469082, MY52510045, MY52520024, MY52529027, SG53470003, TW47040218

No display after power on the unit.

Parts Required:

P/N Description Qty.

NONE

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
MODIFICATION RECOMMENDED			
ACTION X ON SPECIFIED FAILURE CATEGORY: [[]] AGREEABLE TIME	STANDARDS LABOR: 0.5 Hours		
LOCATION [[]] CUSTOMER INSTALLABLE CATEGORY: [[]] ON-SITE (active On-site contract required) X SERVICE CENTER [[]] CHANNEL PARTNER	SERVICE [[]] RETURN INVENTORY: [[]] SCRAP [[]] SEE TEXT USED [[]] RETURN PARTS: [[]] SCRAP [[]] SEE TEXT		
AVAILABILITY: PRODUCT'S SUPPORT LIFE	NO CHARGE AVAILABLE UNTIL: 1 April 2015		
[[]] Calibration Required X Calibration NOT Required	PRODUCT LINE: GM AUTHOR: SJ		
ADDITIONAL INFORMATION:			

© AGILENT TECHNOLOGIES, INC. 2014 PRINTED IN U.S.A.

Agilent Technologies

Page 1 of 2

March 24, 2014

Page 2 of 2 34405A-07

Situation:

34405A customers within the serial number listed might experience no display after power on the unit. This is due to the display cable is not fully inserted to the connector.


Solution/Action:

1. Power on the unit, if the unit has been powered on but there is no display on the LCD, there is a high probability that the display cable is not fully inserted into the connector. Please send the unit to nearest Service Center to tighten the display cable.

Steps to tighten the display cable to the connector:

- Follow the steps in the page 113-116 of User's and Service guide (http://cp.literature.agilent.com/litweb/pdf/34405-91000.pdf)to remove the cover of the 34405A.
- Tighten the two ribbon cable connectors on the front panel as per picture below:





- Ensure the display cable is fully connected to the connector.
- Assemble the 34405A.
- Verify the display is working by power on the unit.

Revision History:

	Revision Number	Date	Author	Reason For Change
	1.0	24 March 2014	SJ	As published
ſ				