

4338B-02

S E R V I C E N O T E

Supersedes:
NONE

4338B Milliohmmeter

Serial Numbers: ALL

Design changes in 4338B cable assembly

Parts Required:

P/N	Description	Qty.
04339-61651	Cable Assembly	1
04339-40003	Cover	1
04339-40004	Cover	1
0515-1550	Screw-Machine	1
3050-0891	Washer-Flat	1

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:	
INFORMATION ONLY	
AUTHOR: LS	PRODUCT LINE: WN
ADDITIONAL INFORMATION:	

© AGILENT TECHNOLOGIES, INC. 2012
PRINTED IN U.S.A.

February 17, 2012

Rev. 19



Agilent Technologies

Situation:

New designed cable assembly (04339-61651) might not be able to be fitted in properly in the older design housing of shunt connector (04339-60003) due to design change in cable assembly.



Figure 1-1: Cable Assembly Design Comparison

Solution/Action:

Whenever cable assembly (04339-61651) is purchased, it is highly recommended to purchase the redesigned upper housing (04339-40003) and bottom housing (04339-40004) together.

The screw (0515-1550) and washer (3050-0891) are common part for both old and new designs and could be reused in new housing.

For ease of repairing, it is highly recommended to replace the whole shunt connector (04339-60003).