

## S E R V I C E N O T E

SUPERSEDES: None

**4395A Network/Spectrum/Impedance Analyzer**

Serial Numbers: 4395A: JP1KE00276 / JP1KE00317

**Use of GSP PN E4970-66551 and LCD PN 2090-0574 may cause a display problem**

To Be Performed By: Agilent-Qualified Personnel

**Parts Required:**

P/N	Description	Quantity
E4970-66553	GSP	1

**Situation:**

The configuration of the GSP PN E4970-66551 and LCD PN 2090-0574 may cause an intermittent display problem (all white image is displayed continuously after power on).

**Solution / Action:**

When the GSP PN E4970-66551 become defective, new replacement GSP PN E4970-66553 must be used.

DATE: July 1998

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

**INFORMATION ONLY**

AUTHOR:

ENTITY:

ADDITIONAL INFORMATION:

KW

3355