S E R V I C E N O T E

SUPERSEDES: None

8563 E Series Portable Spectrum Analyzers

Serial Numbers: See below

A1A2 RPG Assembly and A1 Keyboard Part Number Change

Duplicate Service Notes:

8560E-23	Serial Numbers: 0000A00000/3728A03197
8561E-19	Serial Numbers: 0000A00000/3728A02040
8562E-11	Serial Numbers: 0000A00000/3728A00517
8563A-25	Serial Numbers: 0000A00000/3729A04268
8563E-23	Serial Numbers: 0000A00000/3728A07704
8564E-18	Serial Numbers: 0000A00000/3728A00928
8565E-18	Serial Numbers: 0000A00000/3728A00768

To Be Performed By: Agilent-Qualified Personnel, Customer

Parts Required: See Text

Situation:

The original A1A2 Rotary Pulse Generator (RPG), 0960-0745, has been discontinued by the manufacturer. A new RPG, 1990-1525 is used in all instruments with serials above those listed. To accomodate the new RPG, the A1 Keyboard Assembly and the RPG knob were also changed. The old parts are kept on Replacement for older units, so retrofits are not necessary.

Continued

DATE: January 1999

ADMINISTRATIVE INFORMATION

ION:				
INFORMATION ONLY				
ENTITY:	ADDITIONAL INFORMATION:			
5320				
	INFORMATI ENTITY:			

© 1999 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



Page 2 Service Note 8563E-23

Solution / Action:

Order replacement part numbers for the RPG, keyboard and knob according to the table below.

Description	P/N for Old Serials	P/N for New Serials
A1A2 RPG	0960-0745	1990-1525
A1 Keyboard Ay	08562-60140	08562-60190
RPG Knob	0370-3069	5041-9610