MODIFICATION RECOMMENDED - CORRECTS MANUFACTURING OR DESIGN DEFECTS

E4446A-07

SERVICE NOTE

Supersedes: NONE

E4446A and E4448A

Serial Numbers: [0000A00000 / 9999Z99999]

Instruments with Firmware version A.05.06 may fail frequency response above 26.4 GHz or above. This issue is only observed with PSA Firmware version A.05.06.

Please upgrade the instrument to PSA firmware version A.05.07 or later. The firmware can be downloaded from the following URL:

www.agilent.com/find/psa_firmware

To Be Performed By: Agilent-Qualified Personnel or Customer

Parts Required:

P/N Description Qty.

None

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
MODIFICATION RECOMMENDED		
ACTION CATEGORY:	X IMMEDIATELY [[]] ON SPECIFIED FAILURE [[]] AGREEABLE TIME	STANDARDS: LABOR: 0.5 Hours
LOCATION CATEGORY:	X CUSTOMER INSTALLABLE [[]] ON-SITE [[]] SERVICE CENTER	SERVICE [[]] RETURN USED [[]] RETURN INVENTORY: [[]] SCRAP PARTS: [[]] SCRAP [[]] SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: Support Life
AUTHOR: BNN	PRODUCT LINE: 12	
ADDITIONAL INFORMATION:		

© AGILENT TECHNOLOGIES, INC. 2004 PRINTED IN U.S.A.



Page 2 of 2 E4446A-07

Situation:

Instruments with Firmware version A.05.06 may fail frequency response above 26.4 GHz or above. This issue is only observed with PSA Firmware version A.05.06.

Solution/Action:

Please upgrade the instrument to PSA firmware version A.05.07 or later. The firmware can be downloaded from the following URL:

www.agilent.com/find/psa_firmware