J6828A-01

# S E R V I C E N O T E

Supersedes: NONE

# J6828A 4 Port OC-3/STM1 LIM Multiplexor

Serial Numbers: [US00000000 / US99999999] or "ALL"

After upgrading the power supply for the J6828A to 0950-5095, mounting the new supply in the rack-mount requires two additional pieces of sheet-metal.

## **Parts Required:**

| P/N       | Description        | Qty. |
|-----------|--------------------|------|
| 5002-9558 | Power supply tray  | 1    |
| 5002-9559 | Power supply clamp | 1    |

# **ADMINISTRATIVE INFORMATION**

| SERVICE NOTE CLASSIFICATION: |   |   |  |
|------------------------------|---|---|--|
| MODIFICATION AVAILABLE       |   |   |  |
| ACTION<br>CATEGORY::         | AGREEABLE TIME  | [[]] PERFORMANCE ENHANCEMENT<br>X SERVICE / RELIABILITY ENHANCEMENT |  |
| LOCATION<br>CATEGORY:        | X CUSTOMER INSTALLABLE [[]] ON-SITE [[]] SERVICE CENTER [[]] CHANNEL PARTNERS | AVAILABILITY: September 1, 2011                                     |  |
| AUTHOR: DM                   |   | PRODUCT LINE: 2J  |  |
| ADDITIONAL INFORMATION:      |   |   |  |

© AGILENT TECHNOLOGIES, INC. 2009 PRINTED IN U.S.A.



August 11, 2009

Rev. 16

Page 2 of 2 J6828A-01

## **Situation:**

The addition of these sheet-metal parts allows the new power supply to be attached to the rack-mount kit.

#### **Solution/Action:**

Please refer to the pdf document 5972-0666 (Rack mount opnote)

- 1) Remove the Adapter Anchor Bracket. Remove the power supply. Remove the Monitor Tap Anchor Bracket for J6828A. Do not discard connector HW as it will be re-used.
- 2) Replace the Monitor Tap Anchor bracket with the Power Supply Tray.(5002-9558)
- 3) Replace the Adapter Anchor Bracket with the Power Supply Clamp. (5002-9559)