A MODIFICATION ONLY - DOES NOT COMMUNICATE

N2620A-01

S E R V I C E N O T E

Supersedes: None

FrameScope Pro (N2620A) Software Upgrade recommended.

Serial Numbers: [0000A00000 / 9999Z99999]

It is recommended that you upgrade your N2620A for the best testing performance.

IMPORTANT: N2620A software version 1.2.1 had an issue with the battery charging level. A fully charged battery would display a level of zero percent. This issue would imply that the N2620A battery pack (N2595A-096) was defective. To correct this issue, please upgrade the N2620A to version 2.1.5 (or later).

Parts	Required:

P/N Description Qty.

NONE

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR: JRD PRODUCT LINE: PL PW

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2005 PRINTED IN U.S.A.

Agilent Technologies

October 10, 2005

Page 2 of 2 N2620A-01

Situation:

It is recommended that you upgrade your N2620A for the best testing performance. There have been new software revisions (for the N2620A) to provide performance enhancements.

IMPORTANT: N2620A software version 1.2.1 had an issue with the battery charging level. A fully charged battery would display a level of zero percent. This issue would imply that the N2620A battery pack (N2595A-096) was defective. To correct this issue, please upgrade the N2620A to version 2.1.5 (or later).

Solution/Action:

The N2620A software is available at: (www.framescope.com)
Upgrading the N2620A to the latest revision of software will provide the N2620A with enhanced performance.