N8974A-06

SERVICE NOTE

Supersedes: NONE

N8974A Noise Figure Analyzer

Serial Numbers:

GB44460118- GB44460140 MY45270107- MY45270244 SG45270101, SG45270102

"Microwave Noise Greater than Signal" error message on the screen

To Be Performed By: Agilent service center or Customer

Parts Required:

P/N Description Qty.

N8974-61014 Microwave Front End Assembly 1

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
MODIFICATION RECOMMENDED			
ACTION CATEGORY:	<pre>[[]] IMMEDIATELY X ON SPECIFIED FAILURE [[]] AGREEABLE TIME</pre>	STANDARDS: LABOR: 4 Hours(Includes Repair and Calibration)	
LOCATION CATEGORY:	X CUSTOMER INSTALLABLE [[]] ON-SITE X SERVICE CENTER	SERVICE [[]] RETURN INVENTORY: [[]] SCRAP [[]] SEE TEXT	USED [[]] RETURN PARTS: X SCRAP [[]] SEE TEXT
AVAILABILITY:	Till November 2010	NO CHARGE AVAILABLE UNTIL:	1 st December 2010
AUTHOR: D.C.	PRODUCT LINE: 12		
ADDITIONAL INFORMATION:			

© AGILENT TECHNOLOGIES, INC. 2007 PRINTED IN U.S.A.



Page 2 of 2 N8974A-06

Situation:

Instruments within the listed serial range may fail and display the error message "Microwave Noise Greater than Signal". There could be various reasons for this failure message, one of them being the Microwave Front End Assembly, N8974-60001 in the unit.

Solution/Action:

Agilent service centers should troubleshoot the problem. If it is found due to the Microwave Front End assembly, from the front panel of the analyzer go to [System] { More} {Show Hardware} and check the part number for the "Microwave FE". If it is N8974-60001, the assembly should be replaced by the kit part number N8974-61014, as mentioned in the service note and a full calibration should be performed on the instrument.