

Modification Recommended Service Note

Supersedes:
NONE

N9048B PXE EMI Receiver

Serial Numbers: MY59290103, MY59290104, MY59290105, MY59290118, MY59290119, MY59290123, MY59290148, MY59500028, MY60300111, MY60450101, MY61390105, MY61390113, MY62220123, MY62220127, MY63030111, MY63072015, MY63472028, MY63472003

The Problem – Characterize Noise Floor required prompt even Characterize Noise Floor is performed.

Parts Required:

NONE. Software update only

ADMINISTRATIVE INFORMATION

ACTION	<input type="checkbox"/> ON SPECIFIED FAILURE	STANDARDS		
CATEGORY:	<input checked="" type="checkbox"/> AGREEABLE TIME	LABOR:	0.5 Hours	
LOCATION	<input checked="" type="checkbox"/> CUSTOMER INSTALLABLE (No Parts involved)	SERVICE:	<input type="checkbox"/> RETURN	USED <input type="checkbox"/> RETURN
	<input checked="" type="checkbox"/> SERVICE CENTER	INVENTORY:	<input type="checkbox"/> SCRAP	PARTS: <input type="checkbox"/> SCRAP
CATEGORY:	<input type="checkbox"/> ON-SITE (<i>active On-site contract required</i>)		<input type="checkbox"/> SEE TEXT	<input type="checkbox"/> SEE TEXT
	<input type="checkbox"/> CHANNEL PARTNERS			
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	NO CHARGE AVAILABLE UNTIL:	Aug 1, 2025	
	<input type="checkbox"/> Calibration Required	PRODUCT LINE:	12	
	<input checked="" type="checkbox"/> Calibration NOT Required	AUTHOR:	YC	

ADDITIONAL INFORMATION:

Situation:

After the Characterize Noise Floor alignment is expired and Characterize Noise Floor alignment is performed, found that SystemNoiseModelDensityForTDSAlgorithm alignment is failing. This issue was fixed with XA30 but there is regression issue with firmware revision XA36, XA37 and XA38.

The issue only appears on instruments with option 503 and WF1 and with the serial numbers shown above.

Solution/Action:

Download and install instrument software A.39.00 or later. Perform the Characterize Noise Floor routine. Press System (the gear icon in the upper right portion of the instrument screen), Alignments, Advanced, Characterize Noise Floor.

Instrument software is available at:

https://www.keysight.com/find/xseries_software

Revision History:

Date	Service Note Revision	Author	Reason for Change
01 Aug 2024	01	Yin Chei, Wong	As Published