

PRIORITY SAFETY – REQUIRES IMMEDIATE REPAIR ACTION AND SPECIAL EFFORT TO CONTACT CUSTOMERS

SJ50-06B-S

S E R V I C E N O T E

Supersedes:
SJ50-06A-S

Agilent SJ50 Series II Anorad Gantry Optical Board Test System

Serial Numbers: IE 41500303 - IE 42200207
SG41500000 – IE 41500102

POSSIBLE SERIOUS INJURY

WARNING

Pinch Hazard accessible through the side openings of the system

To Be Performed By: Agilent-Qualified Personnel Only

Parts Required:

P/N	Description	Qty.
5186-5381	SJ safety upgrade kit	1
5186-5383	XL safety upgrade kit	1

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
PRIORITY SAFETY		
ACTION CATEGORY: IMMEDIATELY	STANDARDS: LABOR: 1.0 Hours	
LOCATION CATEGORY: ON-SITE	SERVICE INVENTORY: SCRAP	USED PARTS: SCRAP
AVAILABILITY: End Of Support		
AUTHOR: Martin Boyce PRODUCT LINE: 80		
ADDITIONAL INFORMATION: 5186-5381 and 5186-5383 are orderable through SPD (SERVICE PARTS DELIVERY) at 1-800-816-8650.		
Reference the service note number in the activity description field of the SR.		

© AGILENT TECHNOLOGIES, INC. 2005
PRINTED IN U.S.A.



March 10, 2005

Situation:

If the SJ50 Series II Anorad Gantry System has power applied and service personnel or operators access the inside of the system through the side openings, their hand can be caught in the Gantry, causing severe injury.

Solution/Action:

To install Safety Guards to protect against potential pinch hazard points on the SJ50 Series II Anorad Gantry System.

To install the gantry safety guard kits and follow the Installation Procedure 5186-5364 included in the "Safety Guard Kits" 5186-5381 and 5186-5383.

Note:

Once you have completed the installation of the "Safety Upgrade Kit" fill out and install the Service Note label (Part Number N7200-84366) on the SJ50 Series II near the serial number plate at the rear of the machine.

After completion of this Service Note send an email with the SJ50 Series II Serial number and state the Service Note Identification Number to: MTBUSERVICENOTES@agilent.com