U1273AX-07

# Modification Recommended Service Note

Supersedes: NONE

## U1273AX Handheld Digital Multimeter, 4½ Digit, OLED Display

Serial Numbers: Affected serial numbers are listed on page 2.

The Problem – Handheld DMM with specific serial numbers could have a faulty temperature probe adapter (U1184A).

### Parts Required:

P/N Description Qty.

U1184-64101 Temperature Probe Adapter 1

#### ADMINISTRATIVE INFORMATION

ACTION CATEGORY:	[X] ON SPECIFIED FAILURE [[]] AGREEABLE TIME	STANDARDS  LABOR: 0.25 Hours		
LOCATION CATEGORY:	[[]] CUSTOMER INSTALLABLE [[]] ON-SITE (active On-site contract required) [X] SERVICE CENTER [[]] CHANNEL PARTNERS	SERVICE: [[]] RETURN USED [[]] RETURN INVENTORY: [[]] SCRAP [X] SEE TEXT [[]] SEE TEXT		
AVAILABILITY: PRODUCT'S SUPPORT LIFE		NO CHARGE AVAILABLE UNTIL: 29 June 2021		
[[]] Calibration Required [X] Calibration NOT Required		PRODUCT LINE: GM AUTHOR: WY		

ADDITIONAL INFORMATION:



#### Situation:

U1273AX Handheld digital multimeter with the serial number listed below could have a faulty temperature probe adapter (U1184A).

MY58500002	MY59089027	MY59099008
MY59089004	MY59099001	MY59099018
MY59089021	MY59099002	


A faulty temperature probe adapter will cause the meter to show "OL" when the temperature probe adapter with a probe is plugged into the input jacks of the handheld meter.

Users will not be able to perform temperature measurement when using this faulty temperature probe adapter.

#### Solution/Action:

Perform the steps below to verify your temperature probe adapter:

- 1. Select temperature measurement on your handheld meter.
- 2. Insert the temperature probe adapter with a probe into the input jacks of the meter.



- 3. When a faulty temperature probe adapter is plugged in, your meter will show "OL" (open thermocouple).
- 4. If the temperature probe adapter is verified faulty, kindly contact Keysight Customer Contact Center at <a href="https://www.keysight.com/find/contactus">www.keysight.com/find/contactus</a> to return the temperature probe adapter and get a new replacement part.

**Revision History:** 

Date	Service Note Revision	Author	Reason for Change
29 June 2020	01	WY	As Published