
6030A-13



DATE: 22 February 1992

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
MODIFICATION RECOMMENDED		
ACTION CATEGORY:	<ul> <li>IMMEDIATELY</li> <li>ON SPECIFIED FAILURE</li> <li>AGREEABLE TIME</li> </ul>	STANDARDS: Labor 1.0 Hour
LOCATION CATEGORY:	<ul> <li>CUSTOMER INSTALLABLE</li> <li>ON-SITE</li> <li>SERVICE CENTER</li> </ul>	SERVICE     RETURN     USED     RETURN       INVENTORY:     SCRAP     PARTS:     SCRAP       SEE TEXT     SEE TEXT     SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: 28 February 1994
AUTHOR: BH	ENTITY: 2100	ADDITIONAL INFORMATION:

© 1992 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



## Solution/Action:

Reconnect the W8 ribbon cable. Use RTV to secure the W8 connector to the J5 mating connector on the A2 assembly. Put a 8 mm (0.313 in) size spot bridging the W8 / J5 connectors. Bridge the connectors with an RTV spot at each end as shown in figure 1.




Figure 1