E3610A-07 <u>S E R V I C E N O T E</u>

Supersedes: E3610A-06

E3610A – Single Output Manual DC Power Supply

Serial Numbers: 3111K00101 / KR09999999, MY40000001 / MY40004015

This modification is required to eliminate oscillation when the output voltage and/or load conditions are changed.

Parts Required: P/N

Qty.

NONE

ADMINISTRATIVE INFORMATION

Description

SERVICE NOTE CLASSIFICATION:			
MODIFICATION RECOMMENDED			
ACTION CATEGORY:	X ON SPECIFIED FAILURE [[]] AGREEABLE TIME	STANDARDS LABOR: 1.0 Hours	
LOCATION CATEGORY:	X CUSTOMER INSTALLABLE [[]] ON-SITE X SERVICE CENTER [[]] CHANNEL PARTNER	SERVICE [[]] RETURN INVENTORY: [[]] SCRAP [[]] SEE TEXT	USED [[]] RETURN PARTS: X SCRAP [[]] SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	NO CHARGE AVAILABLE UNTIL: Support Life	
AUTHOR: LCH		PRODUCT LINE: WC	
ADDITIONAL INFORMATION:			

© AGILENT TECHNOLOGIES, INC. 2009 PRINTED IN U.S.A.



Situation:

The output of the E3610A will oscillate if the load is changed from No Load to Full Output. The oscillation will also occur if the output voltage is operated from 1 volt to Full Output voltage. The oscillation frequency is about 30kHz and the amplitude is about 0.62 volts.

When the instrument is operated at about 3.3 volts & 1.4 amps for about 10 minutes, the "CV" Constant Voltage indicator and the "CC" Constant Current indicator may also be turned on. These are front panel indicators.

Solution/Action:

Removing the diode "CR8" P/N 1901-0327 will eliminate the oscillation problem. To remove "CR8" carefully cut the part out. When "CR8" is being removed, be careful not to cut any printed circuit board traces. When "CR8" is removed the instrument does not require calibration. It is recommended that the instrument be checked for proper performance.

The following list of serial numbers have been modified and these instruments have been fully tested at factory

MY40002193 2238, 2513, 2766, 2776, 3602, 3816, 3817, 3818, 3820, 3950, 3975, 3995, 3996, 4013, 4014